## PARTS FOR MODEL MC-2Q PUMP

	<u>PART #</u>		NAME OF PART	<u>QTY REQ'D</u>
*	MC-102Q	**	SHAFT-SEAL ASSEMBLY	1
	M-1Q		MAIN HOUSING	1
	M-4Q		SECONDARY GEAR HOUSING	1
	M-3		SHAFT END COVER	1
	M-2Q		GEAR END COVER	1
*	MS-5Q		DRIVE GEAR (2 PIECES FIXED TOGETHER)	1
	(*M-6QR)		IDLER GEARS WITH BUSHINGS (RIGHT)	2
	(*M-6QL)		IDLER GEARS WITH BUSHINGS (LEFT)	2
*	T-9L		IDLER GEAR SHAFT	4
	T-10		BUSHING FOR IDLER GEAR (3 PER GEAR REQ'D)	12
*	TS-11		SHAFT BUSHING FOR HOUSING	2
*	TC-11		SHAFT BUSHING FOR SECONDARY GEAR HOUSING	1
	MS-15		BEARING RETAINER PLATE WITH GREASE SEAL	1
*	410120		GREASE SEAL	1
	1/4-20Tx5/8L			8
	3/8-16Tx1-1/2L			12
	3/8-16Tx5L			16
	14 PLUG SQ HD		1/4"-PIPE PLUG	3
	104 CUP 6227-19		BLEEDER CUP	1
*	6227-19	**	O-RING FOR TS-11	1
	MC-33		SQUARE KEY, 1/4x1/4x1-1/2L	1
	L-1 GREEN		LABEL PLATE (INSTRUCTION)	1
	L-3 RED		LABEL PLATE (SERIAL NO.)	1
	L-6 RED		LABEL PLATE (INSTRUCTION)	1

## \* **RECOMMENDED SPARE PARTS**

## \*\* LIQUID BEING PUMPED <u>MUST</u> BE SPECIFIED

NOTE:

## When ordering parts, the model number and serial number of the pump in which the parts will be used <u>MUST</u> be given.

(See metal name plate on pump for this information)